

BROTHER

TN-420 BROTHER HL-2130/2240

TN-450 BROTHER HL-2130/2240 DCP-7070/7060

TN-580 BROTHER HL-5240/5250/5280 DCP-8080/8085

TN-1060 BROTHER HL-1110/1112/1212 DCP-1512/1610W

TN-350 BROTHER HL-2040/2070 DCP-7010/7220

TN-360 BROTHER HL-2140/2170 DCP-7040 MFC-7440

TN-570 BROTHER HL-5140/5150 DCP-8020/8040

TN-720 BROTHER DCP-8110/8155/HL-5450/6180/8710

TN-750 BROTHER HL-5450/5470DW DCP-8150/8155

TN-850 BROTHER HL-L5100/L5600DN/L6200/L6400DW

TN-660 BROTHER HL-L2300D/L2320D/L2340DW DCP-L2540W/L2560DW

TN-880 BROTHER MFC-L6700/6750/L6800/L6900

TN-890 BROTHER HL-6400 MFC-L6900

DR-350 BROTHER DRUM HL-2040/2070 DCP-7010/7220

DR-580 BROTHER DRUM HL-5240/5250/5280 DCP-8080/8085

DR-720 BROTHER DRUM HL-5450/5470DW DCP-8150/8155

DR-1060 BROTHER DRUM HL-1110/1112/1212 DCP-1512/1610W

DR-2340 BROTHER DRUM HL-L2300D/L2320D/L2340DW DCP-L2540W/L2560DW

DR-3460 BROTHER HL-L5100/5600DN HL-L6200DW HL-L6400 MFC-L5800/L6900